


GUIDE TO - SETTING UP, PUTTING AWAY AND RECHARGING PORTABLE LIGHTS.

KIT REQUIRED:-

- 6 Floodlight Stands (labelled to show where they should be positioned), 6 Lithium Batteries,
4 Bungee Cords if windy (found in the box located by the Batteries). Torch (which you need to provide)


SETTING UP LIGHTS AND ATTACHING BATTERIES.

1. Position lights on the court 2 at each end and 2 in the middle by the net. (See below).



USE THEM ON ANY COURT APART FROM COURT 4 BY THE ROAD!



2. Open out the TRIPOD LEGS.
 3. Extend the Top Section, which has the lights on, and lock using the thumb wheel locking mechanism.
 4. Extend the Middle Section and lock, using the thumb wheel locking mechanism.
 5. Once fully extended the lights should reach over the height of the stop netting.
 6. Attach the lead to the battery, making sure the pin on the connector is in the correct position.
 7. Tighten the connector by twisting the barrel now covered with Green & Yellow tape BUT not the rest of the connector as this may break the contacts inside.
- 
8. Switch on the light by pressing and releasing the ON switch on top of the battery. Once for 33% power, twice for 66% and thrice for 100%. To switch off, press the ON button and hold until lights switch off.
 9. The Battery can then be hung on the lowest thumb wheel by the strap, **BUT LIFT IT USING THE STRAP NOT THE CABLE**, as this will damage the contacts inside the connector.
 10. Repeat points 2 - 9 for all of the Floodlights.
 11. The 2 Lights located either side of the Net do not have to be fully extended!
 12. If it is windy, there are 4 Bungee Cords to secure the lights, located in each corner, to the stop netting!

PUTTING AWAY LIGHTS AND CHARGING BATTERIES.

1. When play has finished, switch off the battery by pressing the ON button and holding it down.
 2. Carefully detach the battery by twisting the locking barrel covered with Green & Yellow tape and release.
 3. Lower the lights, start with the Middle Section first by releasing the thumb wheel and then the Top Section.
 4. Collapse the Tripod Legs by releasing the Thumb Wheel.
 5. Raise the Leg Section upwards. The height of the stand should now be about shoulder height!!
 6. Ensure ALL Thumb Wheels have been locked before taking each Stand back to the Gents Changing Room.
 7. Lay each stand down on their marked shelf.
 8. Take the batteries, making sure first that they are switched off, & attach the Charger in exactly the same way as you connected the light leads and secure with the locking barrel covered with Green & Yellow tape.
 9. The Battery Charger should, when switched on at the mains, shine a RED Light to show it is charging.
 10. The Battery is fully charged when the Light shines GREEN & can be disconnected. Switch OFF the Power.
- N.B. The Charger stops charging when the Battery is Full.

PLEASE TREAT THE LIGHTS WITH RESPECT & LEAVE THEM AS YOU WOULD EXPECT TO FIND THEM!